



How To Update Software Ferguson eXtreme Action CAM



Remark:

- Before updating, please make sure the camera is full of charge. To avoid it will turn off while it is updating.
- It's better to charge while is in updating.
- Please don't change the software file name.

While updating the software, please do it as following steps:

1. Put the software into microSD card, and please note microSD card don't have other files.
2. Insert the microSD card into camera, and press the power button  to turn on.
3. And then, please press the wifi button . Then camera will update automatically.
4. During updating the software, the screen is on and it shows camera are updating now. Once finished updating, the screen will turn off to black.

