

DVP868HD

 **SOFTWARE (FIRMWARE) UPDATE**

 **AKTUALIZACJA
OPROGRAMOWANIA (FIRMWARE)**

ENGLISH

POLSKI



USB



DVD

SOFTWARE (FIRMWARE) UPDATE

Method of Upgrade:

- 1 Unzip and copy .BIN file to USB memory.
- 2 Turn on DVD player and insert USB memory to USB port.
- 3 DVD player will detect update file and display info on TV screen.
- 3 Press "OK" or just wait 20 seconds.
- 4 The software upgrading takes a few minutes to be complete.
- 5 When the software is successfully upgraded, the set restart.
- 6 The CD tray opens itself. Remove the USB memory.
- 7 Restore default settings (menu SYSTEM SETUP > DEFAULT > RESET).



AKTUALIZACJA OPROGRAMOWANIA (FIRMWARE)

Procedura aktualizacji:

- 1 Rozpakuj archiwum ZIP i skopiuj plik .BIN na pamięć USB (pendrive).
- 2 Włącz odtwarzacz DVD i włóż pamięć USB (pendrive) do portu USB
- 3 Odtwarzacz DVD wykryje plik z aktualizacją oprogramowania i wyświetli informacje o tym na ekranie
- 3 Naciśnij "OK" lub po prostu poczekaj 20 sekund.
- 4 Aktualizacja oprogramowania może zająć parę minut.
- 5 Kiedy proces aktualizacji się zakończy odtwarzacz ponownie się uruchomi.
- 6 Kiedy taca się sama wysunie wyjmij pamięć USB (pendrive).
- 7 Należy przywrócić ustawienia fabryczne (menu SYSTEM SETUP > DEFAULT > RESET)
{strona "USTAWIENIA SYSTEMU" > "NAST. STRONA" > "DOMYŚLNE" > "PRZYWRÓĆ"}.

