



User manual

HEARME 100BT

English





TABLE OF CONTENTS

SAFETY AND MAINTENANCE	2
ABOUT THE INSTRUCTION MANUAL	
MARKINGS AND SIGNS APPLIED TO THE DEVICE	
BASIC INFORMATION ABOUT THE DEVICE	
Main features	
Downloadable software	
Contents of box	4
CHARGING THE SPEAKER	5
PAIRING THE DEVICE	5
SPEAKING OPERATION	5
TROUBLESHOOTING	6
SPECIFICATION	6

SAFETY AND MAINTENANCE

- Do not use this device near any heat sources, such as, radiators, heaters, stoves, or other heat-producing machinery.
- · Do not leave it in direct sunlight.
- Keep the speaker out of children's reach to avoid a choking hazard.
- Clean with soft cloth. Do not use harsh chemicals to clean.
- Do not clean this device, when it is charging. Always unplug from the power source before cleaning the device.
- Do not insert any metal object into the device. Risk of short circuit.
- Do not try to repair or open this device yourself.

ABOUT THE INSTRUCTION MANUAL

Ferguson Sp. z o.o. has made every effort to provide the most current information about its products. Ferguson Sp. z o.o. does not grant any guarantee as to the contents of the present instruction manual and disclaims any implied guarantees concerning market value or suitability for specific purposes. The information contained herein is an instruction intended to enable the correct usage and maintenance of the device.

Ferguson Sp. z o.o. reserves itself the right to introduce amendments, changes or translations of the instruction manual without prior notification thereof. For this reason, we recommend you regularly visit our website in order to obtain the latest information.



MARKINGS AND SIGNS APPLIED TO THE DEVICE



Risk of electric shock - do not open. This notice warns the user not to open the receiver housing. The housing may be opened solely by authorized service technicians.



R&TTE

The logo informs that the receiver conforms to the terms and conditions of Directive 2004/108/EC concerning observance by Member States of electromagnetic provisions regulating compatibility, and to the terms and conditions of Directives 2006/95/EC concerning observance by Member States of provisions regulating low voltage electricity and safety with relation to the handling and operation of electrical equipment.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste.

Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.



Hereby Ferguson Sp. z o.o., declares that the device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. You can find the Declaration of Conformity on www.deklaracje.ferguson.pl

This product has been designed, tested and manufactured according the European R&TTE directive 1999/5/EC.

Double insulation logo.

This logo informs that the devices an electrically safe device, provided that it is used in accordance with the recommendations set forward in the chapter concerning safety.



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct helps to prevent negative consequences for the environmental and human health.



Hot surface mark

CAUTION: HOT SURFACE. DO NOT TOUCH. The top surface over the internal heat sink may become hot when operating this product continuously. Do not touch hot areas, especially around the "Hot surface mark" and the top panel.



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this logo is attached to a product, it means a financial contribution has been paid to the associated national recovery and recycling system.



BASIC INFORMATION ABOUT THE DEVICE

Main features

Operation time: approx. 8hours

USB charging cable included

Speakerphone function

Small dimensions

• Bluetooth version: V3.0+EDR

• Waterproof: IP67

Downloadable software

Ferguson has taken every effort to provide users with software updates in order to ensure that the parameters of the device are up to date. Ferguson reserves itself the right to amend, change or modify the software used in the device as it shall choose and without prior notification. The latest version of the software is available on the website http://www.ferguson-digital.eu

Note:



Please keep in mind that new software may change the functionality of the device. Photographs and descriptions included in the instruction manual are for informational purposes only. If you should notice an error, please report it - we shall make every effort to have it rectified.

Contents of box

Unpack the device and check whether all of the following elements are present:

- Bluetooth speaker Ferguson HearMe 100BT
- User guide
- Charging USB cable



CHARGING THE SPEAKER

- 1. Connect the charging cable to the DC 5V port on the speaker.
- 2. Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. For first time use, a fully charge is recommended.
- 3. A red LED is **ON** while the unit is charging and **OFF** when the speaker is fully charged.

Note:



The device can be only charged with 5V DC charger adaptor or USB.

PAIRING THE DEVICE

Please make sure your cell phone (or any other portable device) supports Bluetooth standard. Specific pairing steps may vary with different devices. Please refer to your device's user manual for further information.

- 1. Turn on your cell phone's Bluetooth function and search for Bluetooth devices. After the search is completed, select "HearMe 100BT" from the Bluetooth device list.
- 2. According to the indication, enter password or PIN No: "0000" or "1234": some cell phones do not need input any password or PIN to pair the speaker, simply press "Pair".
- 3. After successful pairing, a beep sound will be played.

Note:



Once this speaker is paired and connected to your mobile phone successfully, next time when you switch on this speaker, it will connect to your mobile phone automatically as long as the Bluetooth function is turned ON in your mobile. If you need to cut off this pairing, please press long the **PHONE** button.

SPEAKING OPERATION

POWER button: To switch ON/OFF the unit.

VOLUMN / NEXT SONG/LAST SONG button: Long hold to volumn up/down; short press to

play next/last song.

PLAY/PAUSE button: To play or pause music

PHONE button: To answer or hang up the phone calls when incoming calls are indicating.

Note:



- 1. You can press the **PHONE** button twice quickly to redial the last phone call.
- 2. Long press the **PHONE** button to cut off the bluetooth pairing.



TROUBLESHOOTING

The speaker doesn't play

- Make sure the speaker is charged.
- Make sure the speaker and cell phone are connected. Please refer to your cell phone's Bluetooth menu and "Paring Your Device" section.

Cannot pair my cell phone to the speaker

- Make sure the speaker is charged.
- Make sure the speaker and cell phone are in paring mode.
- Make sure the Bluetooth of your cell phone is on; please refer to the cell phone's users' manual.
- Make sure the speaker and your cell phone are within controllable range.

If the problem remains, please do as follows

- Re-charge the speaker.
- Turn off your cell phone and take out the battery, and put it back after.
- Turn on Bluetooth of your cell phone and delete all the paring histories.
- Re-pair your cell phone and the speaker.

SPECIFICATION

- IP grade:IP67
- Bluetooth version: V3.0+EDR
- Frequency range: 2.4GHz
- Power rating: 3W
- SNR: >85dB
- Operating voltage: 3.7V
- Charging voltage: DC 5V
- Charge time: approx. 5hours
- Operation time: approx. 8hours
- Operating distance: 10 meters