



How to update over RS232?

Ferguson offers software upgrade capability for your Ariva using RS232 Null Modem cable. After the upgrade is complete, the receiver will typically perform better. The update of the receiver is carried out yourself.

- (1) Turn off receiver and your PC
- (2) Connect receiver with PC by RS232 Null Modem cable.
- (3) Turn on PC and unzip ZIP file you downloaded software.
- (4) Launch *ArivaUpgrader.exe* program and select the COM port to which you connect the receiver.




- (5) Click **Browse**, to select the firmware file
- (6) Select Include Bootloader





- (7) Click Next to continue.
- (8) Turn on the receiver and wait for the software will be sent to the RAM of the receiver.

How to update over RS232?




(9) After loading, press Next to start programming.



(8) After the end, the receiver will automatically restart and on your computer you will see:

How to update over RS232?



(9) Click **Finished** button, to finish programming via RS232.