Connection to the computer by means of an RS232 Null Modem cable

For connection to a computer, use a Null Modem cable.

Ariva 52E
Ariva 102mini

DB 9 female

1		5
6		9
2		4
7		8
3		3
8		7
4		2
9		6
5		1

DB 9 female

PIN1 — J1
PIN2 — J2
PIN3 — J3
PIN4
PIN5
PIN6
PIN7
PIN8
PIN9