

Remote control



-
-
- (1) D1 indicator: Brighten White when press the remote control button.
 - (2) Show hidden menu.
 - (3) Show main menu.
 - (4) Back to previous or upper interface/menu.
 - (5) Move the highlight or cursor up/down/left/right.
 - (6) OK: to carry out the selection or enter the menu.
 - (7) Press one time to turn on/off air mouse.
 - (8) VOL+/- adjust the sound volume up or down.
 - (9) To switch the receiver standby/power on.
 - (10) turn off/on audio
 - (11) display info or help if supported by application