



 **SOFTWARE (FIRMWARE) UPDATE**

ENGLISH

 **AKTUALIZACJA
OPROGRAMOWANIA (FIRMWARE)**

POLSKI

Ferguson S3



SOFTWARE (FIRMWARE) UPDATE

1. Tablet should be powered by charger.
2. Copy **update.zip** file to the root folder of microSDHC card
3. Power off tablet.
4. Insert microSDHC card to the tablet
5. Press - **(Volume down)** button and **power** button at the same time. Tablet will get into service mode.
6. Press - **(Volume down)** button again to display options.
7. Press - **(Volume down)** button again to switch to the next option: **apply sdcard: update.zip**.
8. Press + **(Volume up)** button to run selected option.
9. Select update.zip file. Use - **(Volume down)** button to switch to the next file/folder
10. Press + **(Volume up)** button to choose selected file. Tablet is now updating firmware.



11. Update takes around 3 minutes.
12. When the progress bar reach 100%, and message **Install from sdcard complete** appears then update is finished.



13. Service menu appears. **Reboot system now** option is selected. Press + (**Volume up**) button to restart tablet.

Note:

Firmware version you can verify in Settings > About MID > Build number

AKTUALIZACJA OPROGRAMOWANIA (FIRMWARE)

1. Tablet powinien być podłączony do zasilania.
2. Skopiuj plik **update.zip** do głównego folderu na karcie microSDHC
3. Wyłącz tablet.
4. Włóż kartę microSDHC do tabletu
5. Naciśnij przycisk - (**ciszej**) i przycisk **power** w tym samym czasie. Tablet przejdzie do trybu serwisowego.
6. Naciśnij ponownie przycisk - (**ciszej**) aby wyświetlić dostępne opcje.
7. Naciśnij ponownie przycisk - (**ciszej**) aby przełączyć na następną opcję: **apply sdcard: update.zip**.
8. Naciśnij przycisk + (**głośniej**) aby uruchomić wybraną opcję.
9. Wybierz plik update.zip. Użyj przycisku - (**ciszej**) aby przełączyć na następny plik/folder.
10. Naciśnij przycisk + (**głośniej**) aby wybrać zaznaczony plik. Tablet aktualizuje oprogramowanie.



11. Aktualizacja zajmuje około 3 minut.
12. Aktualizacja zakończy się kiedy pasek postępu osiągnie 100% i pojawi się komunikat **Install from sdcard complete**.



13. Pojawi się menu serwisowe. Zaznaczone jest opcja **Reboot system now**. Naciśnij przycisk **+** (**głośniej**) aby zrestartować tablet.

Uwaga:

Wersję oprogramowania można sprawdzić w Ustawienia > Informacje o tablecie > Numer kompilacji